

TEASMADE.COM

Goblin 850 and 850k Operating Instructions

- 1** It is always advisable to have older teasmades checked and passed for use by a qualified person. Check the rating plate on the back of the teasmade and make sure that it is suitable for your electricity supply. Your supply should be an alternating current and not subject to interruption. Check the plug - your teasmade must be earthed.
- 2** Always operate the teasmade on a level surface.
- 3** Put the required amount of tea (loose tea or tea bags are both acceptable) in the teapot and place it in position. If the teapot is not placed correctly the buzzer will sound immediately the teasmade is switched on.
- 4** Check the kettle for damage or excessive limescale. Do not operate if there is evidence of either.
- 5** If the kettle is sound, fill it taking care to observe the maximum level pointer inside the kettle. If the kettle is overfilled boiling water may spurt from the vent hole in the lid. Fit the lid securely.
- 6** Place the kettle on its platform and plug it in using the kettle connector (never plug teasmade kettles directly into the mains). Ensure that the platform has freedom of movement. Position the feeder tube over the teapot.
- 7** Turn the teasmade on by flicking the tea switch to the ON position. The neon glows to show that it is on.
- 8** Wait while your tea is made (about 12 minutes).
- 9** You will be alerted that the tea is ready by an enthusiastic gurgling sound, and finally by the buzzing of the alarm.
- 10** Flick the tea switch to the OFF position to silence the buzzer and switch the teasmade off. The neon will stop glowing.